
Nokia E90 Front Screen and Front Keypad Replacement

This guide will show you how to remove the front screen in order to install a new one.

Written By: Cameron Weinberg



INTRODUCTION

If your front screen has stopped working and you need a new one, this guide will show you how to access the front screen.


TOOLS:

- T5 Torx Screwdriver (1)

PARTS:

- Nokia E90 Front Screen (1)

Step 1 — Front Cover



- Start with the phone in the flipped open position.
- You must remove the sticker in the center, below the screen to reveal the center screw.
- Use a T5 screwdriver to remove all three screws, loosening the front screen.


Step 2






- Flip the phone to the closed position and turn to the front screen.
- The front cover will now be loose enough for you to remove by grabbing the edges and lightly pulling the cover off.


Step 3 — Front Screen and Front Keypad



- With the front cover off, the screen and keypad should be loose.

Step 4





- Using a plastic opening tool pry up the cable connecting the LCD screen to the rest of the phone.
- With the cable disconnected, the screen should be free for removal or replacement.

In order to reassemble the front screen or install a new screen, follow the steps provided, in reverse order.

This document was last generated on 2017-06-21 07:17:42 PM.